

Height<16" / 40cm Play Pool Manual

OWNER'S MANUAL

WARNING



NEVER LEAVE YOUR CHILD UNATTENDED – DROWNING HAZARD.

- Only for domestic use.
- Only for outdoor use.
- Children can drown in very small amounts of water. Empty the pool when not in use.
- Do not install the paddling pool over concrete, asphalt or any other hard surface.
- Place the product on a level surface at least 2 m from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires.
- Recommend back towards the sun when playing.
- Modification by the consumer of the original paddling pool (for example the addition of accessories) shall be carried out according to the instructions of the manufacturer.
- Keep assembly and installation instruction for future reference.

SETUP


CHOOSE THE CORRECT LOCATION

- Because of the combined weight of the water inside the pool and the users, it is important that the surface chosen to install the pool is capable of uniformly supporting the total weight for the entire time the pool is installed.
- An adequate drainage system has to be provided to deal with overflow water. During filling, draining or when in use, water may flow out of the pool.
- The surface must be flat and smooth. If the surface is inclined or uneven, it can damage the structure of the pool and the welding point.
- The selected surface must be clear of any type of object. Due to the weight of the water, any object under the pool could damage or perforate the material on the bottom.
- The selected surface must be clear of aggressive plants and weed species. Those types of strong vegetation could grow through the liner and create water leakage. The grass or other vegetation that may cause odor or slime to develop has to be eliminated from the set-up location.
- The selected location must not have overhead power lines or trees. Be sure the location does not contain underground utility pipes, lines or cables of any kind.
- The selected position must be far from house entrance. Do not position any equipment or other furniture around the pool. The water that comes out of the pool during the use or due to a faulty product can damage the furniture inside the house or surrounding the pool.
- **Suggested set-up surfaces:** grass, ground, and all other surfaces that respect the above set-up conditions.
- **Not suggested surfaces:** mud, sand, gravel, deck, balcony, driveway, platform, soft/loose soil or other surface that does not meet the above set-up conditions.

ASSEMBLY

Warning: Adult assembly required.

- Start by inflating the bottom chamber. Then, work your way to the top one and any spare parts (if present). Close the safety valves after inflation. (air pump is not included).
 - When the ring reaches the correct pressure, it should be slightly stiff to the touch. Over-inflating it may cause permanent deformation or damages, due to the high elasticity of the PVC material.
 - **DO NOT OVERFILL** as this could cause the pool to collapse.
- ATTENTION:** Do not leave pool unattended while filling with water.



Proper Water Level

Inflatable Pool

NOTE: All drawings for illustration purpose only. May not reflect actual product. Not to scale.

WATER MAINTENANCE

- Change the water of pools frequently (particularly in hot weather) or when noticeably contaminated, unclean water is harmful to the user’s health.
- Please contact your local retailer to obtain chemicals to treat the water in your pool. Be sure to follow the chemical manufacturer’s instructions.


EMPTY THE POOL

1. Check local regulations for specific directions regarding disposal of swimming pool water.
2. For the inflatable pool, deflate all the air chambers, at the same time push down the wall of the pool to release the water.
For the Fill ‘N Fun pool, push down the wall of the pool to release the water.

NOTE: Drain by adult only!

CLEANING AND STORAGE

1. After use, use a damp cloth to gently clean all surfaces.
NOTE: Never use solvents or other chemicals that may damage the product.
2. Air dry the pool, once pool is completely dry, fold pool carefully and put back to its original packing. If pool is not completely dry, mould may result and will damage the pool.
3. Store in a dry place, with a temperature higher than 15°C/59°F, out of reach of children.
4. Check the product for damage at the beginning of each season and at regular intervals when in use.



Item	Age
52639	12M+

51004; 51005; 51008; 51009; 51012; 51024; 51025; 51026; 51027; 51033; 51034; 51061; 51085; 51103; 51104; 51112; 51115; 51118; 51119; 51120; 51124; 51128; 51145; 51202; 51203; 55004; 55021; 55022; 55028; 55029; 55030; 91007; 91009; 91018; 91028; 91046; 91047; 91060; 91066; 91067; 91069; 91209; 93205; 93403; 93501; 51144; 91079; 91007; 91099; 98006; 98018; 51226	2+
54122; 54445	3+

Refer to the item name or number stated on the packaging. Packaging must be read carefully and kept for future reference.