



Exploded Diagram

Model and code:(PASRW040-P-BP6II-X 100000001307)

1 Complete machine structure explosion diagram



2 Electrical control structure explosion diagram



No.	Code	Name ENG	Qty
1	807000010412	Right Side Panel Assembly	1
2	807000010495	Chassis Assembly	1
3	80100046	Rotory Compressor	1
4	72300010	Titanium Heat Exchanger	1
5	2001-2238	Crossing for Wire	3
6	82500021	Reactor	1
7	80719411	Median Septum Assembly	1
8	807000010406	Back Protective Net	1
9	80602171	Fin Heat Exchanger	1
10	80719401	Motor Bracket Assembly	1
11	80719413	Top Panel of Electrical Box	1
12	807000010407	Top Cover	1
13	20000-330132	Dc Fan Motor	1
14	20000-270004	Axial Flow Fan Blade	1
15	80719406	Retaining Plate	1
16	807000010409	Left Side Panel	1
17	80719400	Wind Deflector	1
18	807000010496	Air Deflector	1
19	807000010405	Front Panel Assembly	1
20	20000-220068	Waterproof Cover	1
21	80719405	Retaining Plate	1
22	80719412	Bracket Assembly	1
23	20000-140484	4-Way Valve Assembly	1
24	81000017	Electronic Expansion Valve	1
25	2001-3605	Pressure Switch	1
26	20000-360157	Pressure Switch	1
27	2000-1460	T-joint	1
28	20000-140150	Needle Valve	1
29	2004-1444	Filter	2
30	83000068	Water Flow Switch	1
31	80719402	Electrical Box Assembly	1
32	20000-360297	Electromagnetic Relay	1
33	4000-3901	Combination Terminal Block	1
34	/	Combination Terminal Block	1
35	80710004	Bracket	1
36	722000000145	Inverter Board	1
37	2000-3257	Power Supply Filter	1